Ilsintech Keyman S1 Specs Provided by www.AAATesters.com

Maintenance Manual

Optical fiber fusion solicer



Please read through this manual completely before its first use.

INDEX



0

		Sofoty auido
-	_	

II. Menu Control ^ 1. Pop-up Menu Registration ^ 2. Setting Auto Heat ^ 3. Setting Errors to be Affected or Ignored ^ 4. Menu Clearing the Record of Total Number of Electric Discharge ^ 5. Setting the Amount of Electric Discharge to be Cleared ^ 6. Changing Maintenance Schedule ^

I	III. Correction Menu	n
	1. Selecting Correction Menu	n
	2. LED Bright Menu	n
	3. Uart Port	10
	4. ARC Settle	10
	5. Motor Setting	11
	6. Check Up	40

7. Splice data Update

IV. Maintenance	40
1. When an Error in Classifying SM and MM in Auto Mode Occurs	40
2. Eccentricity of Position of ARC Discharge	40
3. Abnormal Arrangement of Optical Fibers in Connection Operation	10
4. Occurrence of a Length Difference When Optical Fibers are Initially Placed	10
5. Occurrence of an Error during Booting	16
6. In case of High Connection Loss Rate	47
7. Replacing the Battery	47
8. Replacing the Mirror	10
9. Program Upgrade	10

40

This specification is applied to the maintenance and management of released products of which versions are later than Keyman-S1 Version 3.00.

Keyman S1 has been designed and manufactured for convenient use in indoor or outdoor working conditions. It is easy and simple to use, but please read through this manual completely to avoid failures and safety accidents before you use it. Keyman S1 is designed to easily use, but also contains potential danger. Therefore, this manual contains all necessary instructions to assure safe splice.

□ Please keep this manual with the product all the time.

Ilsintech(Inc.) is not responsible for equipment damage and personal or physical damage caused by improper use or modification.

Warning

If an abnormal condition such as the following occurs, immediately turn off power and disconnect the power source. Next, contact the maintenance service personnel in llsintech(Inc.).

□ If unusual smoke, noise or odor or unusual overheating occurs,

□ If foreign substance or liquid gets inside the splicer, or

□ If the splicer is dropped from a high place or suffers damage

Do not use AC power code other than the allowable power cord indicated. Doing so may cause a fire, electric shock or injury. Use the power code provided with S1.

Do not touch the electrodes when S1 is switched on. High voltage and High temperature from them may cause serious shock or a burn.

Make sure that there is no dust or foreign substance inside the AC plug. Then, Connect AC power cord to the specified charger and the outlet. Unsafe splice may cause smoke, fire, equipment damage, serious injury or death.

Warning

Do not use a voltage other than the allowable power voltage indicated.

AC power supply for the specified charger is AC 100-240V, 50-60Hz.

Please check the AC power supply before using. AC power supply within the improper range may cause electric shock, equipment damage, serious injury or even a death. Abnormally high AC output voltage or frequency from the generator is a common problem. Measure AC output voltage with a circuit tester before connecting AC power cord. Regular inspection is needed because improper high voltage or frequency from the generator may cause serious injury, electric shock, equipment damage or death.

Do not severely pull, heat or modify the provided AC power cord. The use of damaged power cord may cause hazardous conditions such as fire or injury.

Connect only to 3-core AC power cord. Do not connect to 2-core power cord, cable or plug.

To reduce the risk of electric shock, do not touch the AC plug, the AC power

code and the splicer with wet hands.

Do not disassemble AC adapter, battery or the splicer. Any modification to the splicer may cause a fire, electric shock or injury.

When you use external battery, see the following instructions.

□ The use of improper external battery may cause smoke, equipment

damage, or in serious cases burning, injury or death.

 \Box Do not throw the battery into a fire or a garbage dump.

 \Box Do not charge the battery close to flames.

 \Box Do not give severe vibration or shock to the battery.

□ If the battery is not fully charged within 6 hours or green LED

lamp is not on, immediately stop charging and contact llsintech(lnc.)

Do not place any object on AC adapter during charging.

Only use the specified battery charger(S-1B) and the specified battery pack(S-1B). The use of any battery pack other than the specified one may cause smoke or fire, equipment damage, injury or death.

Warning

Only use the specified battery charger(S-11).

Do not use AC power other than the allowable power indicated.

Do not let battery(S-1B) or the terminal of the specified charger be shortcircuited. Excessive current flow may cause damage to the equipment and persons.

Avoid the use of S1 in a hazardous location in which harmful gas or flammable gas can generate. In such conditions, the electrical arc of the fusion splicer can result in bursting or fire.

Do not use compressed gas to clean S1.

If you carry the transport case connected with a belt, first check the belt is strong enough. The worn belt may fail to sustain the case, resulting in equipment loss or injury.

Wear safety glasses for protection from glass fibers. Glass fibers may cause serious damage to eyes or skin tissue.

Do not use the splicer in high temperature conditions. Doing so may cause

equipment loss or injury.

Do not use a splicer in high temperature conditions. Doing so may cause equipment loss or injury.

Caution

During or after heating protection sleeves in the tube heater, do not touch both parts. Injury from high temperature could occur.

Do not place S1 in unstable locations. If the equipment is dropped, injury or equipment damage could occur.

S1 is a precision instrument. It should be handled with care and precision. When transporting it, use its specified transport case to protect it from dust, dust, moisture, shock and impact.

Replace the electrodes the right way.

 \Box Only use the specified electrodes.

 \Box Place the new electrode in the right position.

 \Box Replace the electrodes in pairs.

Not doing so may cause abnormal arc and equipment damage or deterioration

in splice performance.

Only use ethyl alcohol (more than 96 %) to clean the splicer including object

lenses, V-grooves, wind-proof glass, LCD monitor, and the main body.

To prevent modification, discoloration and low performance, do not use any kind of chemicals.

Do not use lubricants including oil and grease for S1. Doing so may cause performance deterioration and equipment damage.

Do not store the equipment in high-temperature or high-humidity conditions. Equipment damage could occur.

Qualified experts should check up technical matters concerning S1. Not doing so may cause fire or electric shock. Please contact qualified service personnel in Ilsintech(Inc.) and get A/S service.



Both Connection Mode and Heater Mode can be registered in Pop-up menu, which allows user to select each mode in a quick manner by pushing either up or down direction key.

	Push 🛆 or V	
	POP UP MENU	
\Rightarrow To activate a mode, select the mode by	1:AUTO .60mm	•
	2:AUTO .60mm 3:MM2 .60mm	
moving the cursor and then push 🔍 key.	4: BLANK	•
	5: BLANK 6: BLANK	
Push Esc to return to previous menu.		L L
	←:Select Esc:Retur	tn 👘

Registering each mode

Connection Mode Registration
 Push Menu Key → Select Connection Mode → Move to the mode to be registered →
 Push Set Key → Pop-up menu registration box appears → Assign a
 number to be used by moving up and down direction keys → Push →
 Completion of the registration

Heater Mode Registration

Push Menu Key \rightarrow Select Heater Mode \rightarrow Move to the mode to be registered \rightarrow Push Set Key \rightarrow Pop-up menu registration box appears \rightarrow Assign a number to be used by moving up and down direction keys \rightarrow Push \rightarrow Completion of the registration



2. Setting Auto Heat

The function of setting auto heat is useful, especially, in performing consecutive connection works. When the wind protection cover is opened after completing a connection, the heater starts to be operating and stops at the end of pre-set time period.

Menu Key \rightarrow Main Menu \rightarrow Select additional function of connection \rightarrow Select basic \rightarrow Set to On or Off in Auto heat

3. Setting Errors to be Affected or Ignored

Errors not affecting the operative function of connection can be either ignored or selected.

Menu Key \rightarrow Main Menu \rightarrow Select additional function of connection \rightarrow Ignore connection errors \rightarrow Set On or Off for each item

4. Menu Clearing the Record of Total Number of Electric Discharge

The total number of electric discharge can be

initialized.



Menu Key \rightarrow Aux \rightarrow Select CLEAR ARC COUNT, in which push, simultaneously, both X, Y Key and \triangle Key.

The total number of electric discharge becomes 0 when selecting Initialize and

pushing Enter key.

5. Setting the Amount of Electric Discharge to be Cleared

The electric discharge amount to be cleared can be set.

Menu Key \rightarrow Main \rightarrow Select Splice Option, in which push, simultaneously, both keys of X, Y and \triangle . The amount of electric discharge to be cleared can be re-set.

6. Changing Maintenance Schedule.

Menu Key \rightarrow Other \rightarrow Select Maintenance, in which push, simultaneously, both X, Y Key and \triangle Key. Change the date.





1. Selecting Correction Menu

Push Menu Key \rightarrow SUB \rightarrow OTHER \rightarrow Select System Setting \rightarrow in which screen, push, simultaneously, both X, Y Key and \triangle Key.



2. LED Bright Menu

This menu is used for adjusting the brightness of camera flashes. A sub menu

appears when selecting this menu.

LED Bright

After adjusting the brightness of flashes by selecting the menu for adjusting the brightness of camera flashes,

LED BRIGHTNESS	
▶ 70	
0 YLED	150
	-
←:Select Esc:Return	

select Menu Key \rightarrow OTHER \rightarrow LED CHECK, in which keep the brightness value between 80~86.

LED Bright (Auto)

This is an automatically adjusted brightness value of LED

flashes which is applied when the device is booted. The

standard value has been set to 83.

	Led bright(auto)	
	83	
0		150
	←:Select Esc:Return	

3. Uart Port

Check if it has been set to Data Download when performing Program Up-Grade.

4. ARC Settle ARC Position Menu used for correcting the centers of arranged optical fibers and ARC

Limittion Re-arc times

Menu for setting re-arc discharge times

ARC settle	
ARC Position	
Limittion Re-arc times	
←:Select Esc:Return	

The number set is the maximum times allowing re-arc discharge.

5. Motor Setting

Menu for setting measuring values of camera motor and X, Y motor The initial setting value of each motor shall be recorded prior to Up-Grade. A screen as next figure appears upon selecting the menu.

MOTOR SETTING

Core Equalization Fiber Type MENU Auto Set Initial Temp Compensation

XY Motor Offset

-:Select Esc:Return

Core Equalization

Menu for correcting images from the camera

- Auto Mode: Menu for setting the reference position of the camera in Auto Mode (Do not change the initially set value)
- Except Auto: Menu for correcting the size of optic fibers' core when conducting ALIGNMENT (Do not change the initially set value)
- Loss Calculation equalize: The control value of camera, which is to be applied in calculating Loss (Do not change the initially set value)

Fiber Type Menu

Menu for correcting image data of optical fibers in Auto Mode

Fiber Type Resister: Menu for setting a standard value for recognizing Fibers in Auto Mode (Do not change the initially set value). The value is automatically adjusted when correcting the motor.

Fiber Type Limit: Menu for setting a threshold value for recognizing Fibers in Auto mode (Do not change the initially set value).

Fiber Total Limit: Menu for setting a threshold value of Fiber data (Do not change the initially set value).

First-Time Compensation: Menu for setting an automatic correction value in Auto Mode (Do not change the initially set value).

Temp Compensation

Menu for setting temperature compensation (Do not change the initially set value).

X, Y Motor Offset

Menu for setting a compensation value when a length difference occurs upon placing right and left fibers

6. Check Up

Motor Setting: A screen which shows the reference line when adjusting the

position of optical fibers (, which are used in replacing a lens or camera)

Fiber Shape Set 1: A standard value used for judging the faulty status of a cut section of optical fibers (Clad Section). The bigger the size of this value is, the less sensitive the fault detection capability becomes.

1Fiber Shape Set 2: A standard value used for judging the faulty status of a cut section of optical fibers' core. The bigger the size of this value is, the less sensitive the fault detection capability becomes.

Fiber Shape Set 3: A standard value used for judging the broken status of optical fibers. The smaller the size of this value is, the less sensitive the function becomes.

7. Splice Data Update

Used in conducting Splice Mode and Heater Mode Update.

X Upon performing Splice Mode and Heater Mode, all existing data is initialized. Extra caution is required.

IV. Maintenance

1. When an Error in Classifying SM and MM in Auto Mode Occurs,

Correct the error according to following steps; Push Menu Key \rightarrow Select OTHER Menu \rightarrow Select DIAGNOSTIC TEST. Place SM Optical Fiber \rightarrow \bigcirc \rightarrow Completion of Correction \rightarrow ESC \rightarrow Return



2. Eccentricity of Position of ARC Discharge

If the position of Arc, which is produced upon connection, is not placed at the middle of optical fibers, which are set opposite each other, and inclined toward the right or left side, perform a correction to place it at the central position. Select Arc Position, and increase or decrease the value toward + direction when the Arc is leaned to



the right side, and - direction when it is leaned to the left side.

3. Abnormal Arrangement of Optical Fibers in Connection

Operation

If connection job is performed while the center of optical fibers is placed at a

wrong position in the process of aligning their centers during connection, correct

the focus of the camera.

Locate and set the position where no malfunction occurs by increasing or decreasing the value after selecting Except Auto Mode.

4. Occurrence of a Length Difference When Optical Fibers are Initially Placed

In case that a length difference occurs when optical fibers are initially placed, first of all, remove all dirt in the V-Groove and clean optical fibers, and re-verify the status.

If the same difference occurs again, perform X, Y Motor Offset illustrated in article 3.4.5.

Select X, Y Motor Offset Menu.

In case that X axis is higher or lower;

Increase X-M toward + direction when it is higher.

Increase X-M toward – direction when it is lower.

In case that Y axis is higher or lower;

Increase Y-M toward + direction when it is higher.

Increase Y-M toward – direction when it is lower.

Select Motor Drive in Other Menu after conducting Set, return and then initialize the camera.

5. Occurrence of an Error during Booting

-Camera Led error

Upon conducting Self Check after inputting power, if Camera Led error is displayed;



Dust Check Error

Upon conducting Self Check after inputting power, if Dust error message is displayed;



6. In case of High Connection Loss Rate

Check the status of electrode and replace it, if it has worn down.

If the electric discharge shows an inclination toward the right or left side in the

screen upon connection, correct the center of discharge by selecting Arc

Position in Correction Menu.

In case that the Arc is leaned to the right side in the screen

Compensate it by increasing it toward + direction

In case that the Arc is leaned to the left side in the screen

Compensate it by increasing it toward - direction

7. Replacing the Battery



Disassemble the batter cover.



Replace the batter after removing battery cables.

8. Replacing the Mirror

Replacement of Wind Protection Cover Mirror

The mirror shall be replaced, if unable to make it clean or remove stains by





Turn off the fusion splicer

- Open the wind protection cover and detach the mirror using a (+) type screwdriver. Use extra caution in separating the mirror because a spring is place behind the mirror.
- Take out the shaft pin placed in the old mirror and insert it into the new mirror, and reassemble it in the reverse order of disassembling.



Be careful not to lose the

Verify whether the mirror has been correctly placed. If it hasn't been assembled in a right manner, optical fibers are not correctly identified.



Into which the spring is inserted

Shaft Pin

Clean the mirror.

Inspect if there are any lines, stripes or stains through the monitor screen

after turning on the machine. Verify the status of lens' surface through X and

Y screens while changing the screen by pushing X/Y keys.

9. Program Upgrade

Data may be changed when Program Upgrade is done; therefore, it is required to separately keep the record of Set values of Correction Menu and verify them after completion of Upgrade.

Core Equalization

Menu for correcting images from the camera

Save in a PC a copy of both Keyman S1_X_XX.bin File and Firm_ware.bin

File, which are used for upgrading the interface adapter.

<u>м</u>

Make a copy of FTDRIVER.ZIP File and save it in a PC after decompressing it.

Push, simultaneously, both C Key and Power Key in the interface adapter.

(If the Logo screen is displayed without freezing the screen, perform it again

after turning off the power).

Connect the interface adapter with PC using a USB Cable.

When a PC message indicating the detection of a new hardware appears,

install FTDRIVER by selecting install.

Set the PC as follow;

Select Control Panel -> System -> Hardware -> Device Manager -> Port



General	Port Settings	Driver Details		
		Bits per second:	115200	•
		Data bits:	8	•
		Parity:	None	•
		Stop bits:	1	<u>•</u>
		Flow control:	None	•
		Ac	lvanced	Restore Defaults

Jecomo			Γ	OK
USB Transfer Sizes				Cancel
Select lower settings to correct Select higher settings for faster	performance problems at lov performance.	v baud rates.		Defaults
Receive (Bytes):	4096 💌			
Transmit (Bytes):	4096 💌			
BM Options		Miscellaneous Options		
Select lower settings to correct r	response problems.	Serial Enumerator	₹	
Latencu Timer (msec):	16	Serial Printer	Г	
Latency Timer (msec):	16 💌	Serial Printer Cancel If Power Off		
Latency Timer (msec):	16 💌	Serial Printer Cancel If Power Off Event On Surprise Removal		
Latency Timer (msec):	16 💌	Serial Printer Cancel If Power Off Event On Surprise Removal Set RTS On Close		

In Windows' All Programs, go to Accessories \rightarrow Communication \rightarrow execute Hyper Terminal

When an error message appears, click Confirm and continue the process.

If a New Connection box appears, enter any number into it and click OK.

If an error message pops up, click OK and continue the process.

X In case of using Windows VISTA, install Hyper Terminal 6.3 first, and then perform the process.

When Connect To box appears, select "Connect using", open the port

which was set in the article, and then execute the port.

🎨 keyman - HyperTerm	ninal				
	srer Help				
Connected 0:00:04	115000 0 N 1	SCROLL CA	PS NUM Capture	Print echo	

Open Save	6	1
Save As	_	
Page Setup Print		
Properties		
Exit Alt+F4		
	_	

-		
	Regnan Alexandre San Alexandre S Alexandre San Alexandre San	
	Enter details for the phone number that you want to diat	
	Country/region: United States (1)	
	Phone number:	
	Connect using:	
	OK Cancel	



When setting the port is completed, select Transfer in the full down menu of Hyper Terminal and click Send.

Select Upgrade Program Keyman S1_X_XX.bin File, which is saved in the PC, by clicking Brows button of Filename. Select Xmodem as a protocol, and click Send.



Download User pro	gram to Serial Flash!	
8888888	Send File	
	Folder: C:\Documents and Settings\Owner\Desktop Filename: C:\Documents and Settings\Owner\Desktop\LLSI Browse Protocol Xmodem	
	Send Close Cancel	

When a message as below appears after the file transfer is completed, turn off the power by pushing emergency reset button.



Push, simultaneously, both ESC key and Power Key together

(If the Logo screen is displayed without freezing the screen and the

interface adapter is operated, perform it again after turning off the

power).

) ൙ 🚿 🖉		
Download Xmodem W download OK to RA Serial F S_Flash Serial F Reboot a SRAM Boo	User program to Serial Flash! aiting def file at 0x08000000 size =0x0012b000 byte M! filesize =0x0012b000 pagesize =0x000009 lash Programming Verify Ok! lash Write O.K. nd then Download Sram Boot!	****** S 10
Xmodem W	aiting	

Download User program	o Serial Flash!	
downloaded file at 0x00 OK to RAM! filesize = Serial Flash Programmin S_Flash Verify 0k! Serial Flash Write 0.K Reboot and then Downloa SRAM Boot Wait Xmodem Waiting \$\$\$	B000000 size =0x0012b000 bytes Send File Image: Chocuments and Settings/Duwner/Desktop Image: Chocuments and Settings/Duwner/Desktop/B_E Browse Protocol: Xmodem Image: Choce Cancel	

Xmodem	file send for keyman	
Sending:	C:\Documents and Settings\Uwner\Desktop\B_EMLSI_Firm_wareU8U/U	
Packet:	167 Error checking: Checksum	
Retries:	0 Total retries: 0	
Last error:		
e File:	21K of 30K	
Flansed:	00:00:07 Bemaining 00:00:03 Throughout 2944 cps	
Liupsou.	ococor monaning, ococor micagipat, 2000 pa	
	Cancel Cps/bps	
	Sending: Packet: Retries: Last error: File: Elapsed:	Sending: C:\Documents and Settings\Dwner\Desktop\B_EMLSI_Firm_ware08070 Packet 167 Error checking: Checksum Image: Checksum Retries: 0 Total retries: Itast error: Image: Checksum File: Image: Checksum File: Image: Checksum File: Image: Checksum File: Image: Checksum Cancel cps/bps





Once the transfer is completed, the interface adapter is automatically

booted with an alarm sound.