


FSM-18R Fusion Splicer



FSM-18R



Detachable Work Table

The FSM-18R fusion splicer is a 4-fiber ribbon splicer with similar versatility and robust nature of the Fujikura 12-fiber ribbon splicer. Well-suited for FTTx or LAN applications, the FSM-18R fusion splicer can splice up to 4 fibers, as well as single fibers.

The enhanced robust features provide resistance to shock, dust, and rain to minimize downtime and improve operational performance and withstands a 30" drop test.

Automated features such as auto-start splicing, auto-start tube heater operation, automatic ribbon fiber identification, and auto-arc calibration reduce operational steps and improve splicing performance. Additional improvements include automatic image orientation when switching the dual position monitor, a large capacity battery option and the ability to charge the battery during splicer operation.

New software included with each splicer provides the ability to download splice data to a PC for splice data reporting, download splicer operating software via the internet to maintain peak performance, and download video images from the splicer to enhance technical support.

Features

- Rugged construction providing shock, dust and moisture resistance
- Dual monitor position with automatic image orientation
- Automatic arc calibration and ribbon fiber identification
- Auto-start tube heater
- Color LCD display and anti-reflective coating for excellent visibility in bright sunlight
- Simultaneous battery charge and splicer operation
- Long life battery (up to 90 splice/heat cycles per charge)
- Detachable work table incorporated into the transit case
- Data and video download software and splicer upgrade software included; software upgrades through PC application via the internet
- Green friendly – RoHS & WEEE compliant

Ordering Information

DESCRIPTION	AFL NO.
FSM-18R Fusion Splicer (machine only) Includes: FH-50-4 Fiber Holders (pair), ADC-13 AC Adapter, ACC-14 AC Cord, JP-05 Splice Sleeve Cooling Tray, USB Cable, Splicer Carrying Strap, Spare Electrodes (pair), Quick Reference Guide, Video Instruction Manual, and Transit Case with Carrying Strap	S014529
FSM-18R Fusion Splicer Kit (with cleaver and stripper) Includes: CT-30 Cleaver, HJS-02 Hot Jacket Stripper, FH-50-4 Fiber Holders (pair), ADC-13 AC Adapter, ACC-14 AC Cord, JP-05 Splice Sleeve Cooling Tray, USB Cable, Splicer Carrying Strap, Spare Electrodes (pair), Quick Reference Guide, Video Instruction Manual, and Transit Case with Carrying Strap	S014530
FSM-18R Fusion Splicer Kit (with cleaver, stripper, battery and cord) Includes: CT-30 Cleaver, HJS-02 Hot Jacket Stripper, FH-50-4 Fiber Holders (pair), BTR-08 Battery, DCC-14 Battery Charge Cord, ADC-13 AC Adapter, ACC-14 AC Cord, JP-05 Splice Sleeve Cooling Tray, USB Cable, Splicer Carrying Strap, Spare Electrodes (pair), Quick Reference Guide, Video Instruction Manual, and Transit Case with Carrying Strap	S014561
One year extended warranty	S012996
Two year extended warranty	S013000

FSM-18R Fusion Splicer

Accessories Recommended for the FSM-18R

DESCRIPTION	AFL NO.
Cleavers and Strippers	
CT-30 Cleaver	S014076
HJS-02 Hot Jacket Stripper	S010340
Fiber Holders (pairs)	
FH-50-4	S013812
FH-50-2	S013808
FH-50-250 (250 µm coated single fiber)	S013800
FH-50-900 (900 µm jacketed single fiber)	S013804
Batteries and Power Cords	
ADC-13 AC Adapter	S014535
ACC-14 AC Power Cord	S014536
BTR-08 Battery	S014540
DCC-14 Battery Charge Cord (BTR-08)	S014541
DCC-12 Power Cord (connects ADC-13 to cigarette lighter socket)	S013552
DCC-13 Power Cord (connects ADC-13 to power source via alligator clips)	S013556

DESCRIPTION	AFL NO.
Miscellaneous	
ELCT2-20A Electrodes	S013532
FST-12	S014012
Portable Tripod Workstation (see product profile for more detail)	S014733
ASW-02 Splicing Workstation (see product profile for more detail)	S010532
JP-05 Splice Sleeve Cooling Tray	S014537
MGS-06 Magnifier (with bracket)	S014555
FAT-04 Fiber Arrangement Tool	S010212
FAA-03A Ribbon Forming Adhesive (4 oz. bottle)	S008720
FAA-03A Ribbon Forming Adhesive (0.5 liter bottle)	S008622
CC-24-18R Transit Case	S014556

Specifications

PARAMETER	VALUE
Model	FSM-18R Fusion Splicer
Applicable Fibers	Single-mode (G.652 & G.657), Multimode (G.651), DS (G.653), NZDS (G.655)
Fiber Count	Single, 2, 4
Cladding Diameter	125 µm
Coating Diameter	Ribbon: 0.25 mm to 0.4 mm; Single: 250 µm and 900 µm
Fiber Cleave Length	10 mm
Typical Average Splice Loss	0.05 dB with SM, 0.02 dB with MM, 0.08 dB with DS, 0.08 dB with NZDS, measured by cut-back method relevant to ITU-T and IEC standards
Splicing Time	Typical 20 seconds with standard single-mode fiber
Arc Calibration Method	Automatic, real-time by using results of previous splice when in AUTO mode, manual arc calibration function available
Splicing Modes	100 preset and user programmable modes
Splice Loss Estimate	Based upon dual camera cladding alignment data
Storage of Splice Result	Last 2000 splice results stored in the internal memory
Fiber Display	X or Y, or both X and Y simultaneously; front or rear monitor display options with automatic image orientation
Magnification	90X
Viewing Method	Dual cameras with 4.1 inch TFT color LCD monitor with anti-reflective coating
Operating Condition	0 to 5,000 m above sea level, 0 to 95% RH, -10 to 50°C respectively
Mechanical Proof Test	1.96 to 2.25N
Tube Heater	Built-in tube heater with 30 heating modes; auto-start function
Tube Heating Time	Typical 50 seconds with FP-5 sleeve, 40 seconds with FP3 (40), 35-55 seconds with Fujikura micro sleeves
Protection Sleeve Length	60 mm, 40 mm, micro
Splice/Heat with Battery	Typical 90 cycles with power save functions activated
Power Supply	Auto voltage selection from 100 to 240V AC or 10 to 15V DC with ADC-13, 13.2V DC with BTR-08 battery
Terminals	USB 1.1 (USB-B type) for PC communication, Mini-DIN (6-pin) for HJS-02/03 and SH-8 tube heater
Wind Protection	Maximum wind velocity of 15m/s. (34 mph)
Dimensions	136 W x 161 D x 143 H (mm) / 5.3 W x 6.3 D x 5.6 H (inches)
Weight	2.1 kg (4.6 lbs) with AC adapter ADC-13; 2.5kg (5.5 lbs) with BTR-08 battery